

BOTANY BAY

TIMBER PRODUCTS

P/
L

SKIRTINGS & ARCHITRAVES



**COLONIAL
VICTORIAN
EDWARDIAN
HERITAGE
ART DECO
BUNGALOW
MODERN
CONTEMPERARY
SPECIALIZED & DADO
CORNICE
PICTURE RAIL**

www.botanybay.com.au

Introduction	3
Colonial Type	4-8
Victorian Type	9-10
Edwardian Type	11-13
Edwardian Type	14
Art Deco Type	15-18
Visual Room	19-20
Bungalow Type	21-22
Modern/Contemporary Type	23-24
Specialized	25
Dado Rails	25-27
Cornices	28
Picture Rails	29
Installation	30
Storage/Handeling/Safety	31



BOTANY BAY PRODUCTS PTY. LTD.

For over thirty years Botany Bay Timber Products have offered a diverse and broad range of Skirtings and Architraves and built a reputation for the highest standards in decorative, traditional and modern moulds. We remain committed to AUSTRALIAN MANUFACTURE in order that we can have ultimate control over the quality and service that we offer.

Our reputation has been built on our founding principles...

Applying our skills and resources to meeting the changing needs and expectations of our customers.

Research and development, to generate ideas, engineering enhancements and production improvements.

A commitment to investment in new technology, automated equipment, a philosophy of non-stop optimisation and development of 'tomorrow's technology.

Developing lasting and durable relationships with our clients. Through sharing our comprehensive know how, our passion for innovation and our experience to enable the (cost) effective application of Botany Bay Mouldings in their project.

The application of these principles have aided in building our reputation for excellence relating to the timely supply of competitive and affordable products.

When it comes to forward thinking in Mould design, craftsmanship and value for money, Botany Bay leads the way. We invite you to browse through our designs and look forward to helping you enhance your building or renovation projects with the latest Botany Bay collection. Decorating your home with moulds is now more exciting than ever. The latest design trends, the most advanced technologies, the widest selection... they are all here in the Botany Bay Collection and designed to inspire.

Enhance your home with mouldings that reflect your personality, enrich your lifestyle and truly complement your architectural choice. From sophisticated and cool, to timeless and traditional, you'll find designs to suit almost every architectural genre.

COLONIAL

Most buildings erected in the first 50 years of Australian settlement were simple and plain. Convict huts, marine barracks, government stores and houses for officials were simple rectangular prisms covered with hipped or gabled roofs often with verandahs supported on wooden columns.



Orbst

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



K Colonial

Width: From 42mm to 240mm
Thickness: 18mm to 32mm



Modern Colonial

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



K Australian Colonial

Width: From 42mm to 240mm
Thickness: 12mm - 32mm




Kilmore

Width: From 86mm to 240mm
Thickness: 18mm - 32mm




NSW Colonial

Width: From 42mm to 240mm
Thickness: 18mm - 32mm




Regency A

Width: From 42mm to 240mm
Thickness: 12mm - 32mm




C4

Width: From 42mm to 92mm
Thickness: 12mm - 32mm




Eagleton

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Rushworth

Width: From 60mm to 120mm
Thickness: 32mm




Colonial E117

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



Glenwood

Width: 67mm to 240mm
Thickness: 18mm - 32mm



BB Lambs Tongue

Width: From 67mm to 240mm
Thickness: 12mm - 32mm



Darley

Width: From 85mm to 240mm
Thickness: 18mm - 32mm



Richmond


Width: 67mm to 240mm
Thickness: 18mm - 32mm

COLONIAL




Swan

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Oakvale

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Jerrara

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



KVictorian

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Kenley

Width: From 110mm to 240mm
Thickness: 18mm - 32mm



Broadwater

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Neutra

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



K Lambs Tongue

Width: From 42mm to 240mm
Thickness: 12mm - 32mm



Maidstone

Width: From 92mm to 240mm
Thickness: 18mm - 32mm



Mana

Width: From 67mm to 240mm
Thickness: 18mm - 32mm




Horsham

Width: 67mm to 240mm
Thickness: 18 mm - 32mm




Rubicon

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Mini NSW Colonial

Width: From 42mm to 240mm
Thickness: 18mm - 32mm



BB Colonial

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Replica

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Mini Replica EXT

Width: 67mm to 140mm
Thickness: 18mm



Roseberry


Width: 67mm to 240mm
Thickness: 18mm - 32mm



Mini Replica


Width: 67mm to 140mm
Thickness: 18mm - 32mm

COLONIAL



Clifton

*Width: 100mm to 240mm
Thickness: 32 mm*




Product: Special Replica

*Width: 67mm to 140mm
Thickness: 18mm - 32mm*



Colonial E12

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*



Waterways

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*


VICTORIAN

Most buildings erected in the first 50 years of Australian settlement were simple and plain. Convict huts, marine barracks, government stores and houses for officials were simple rectangular prisms covered with hipped or gabled roofs often with verandahs supported on wooden columns.




Modern Neutra

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Ultima

Width: 110mm
Thickness: 32mm



BBC Lambs Tongue

Width: From 67mm to 240mm
Thickness: 12mm - 32mm



Balmoral

Width: From 110mm to 240mm
Thickness: 18mm - 32mm




Alvar Special

Width: From 115mm to 240mm
Thickness: 18mm - 32mm



Alvar

Width: From 135mm to 240mm
Thickness: 18mm - 32mm



Rokewood

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Exford

Width: From 85mm to 240mm
Thickness: 18mm - 32mm



Elmore

Width: From 115mm to 240mm
Thickness: 18mm - 32mm

VICTORIAN




Hillside

Width: From 135mm to 240mm
Thickness: 18mm - 32mm



Beveridge

Width: From 67mm to 240mm
Thickness: 18mm - 32mm



Trafalgar

Width: From 60mm to 150mm
Thickness: 18mm to 32mm



Inigo

Width: From 85mm to 240mm
Thickness: 18mm - 32mm




Colonial E14

Width: From 110mm to 240mm
Thickness: 18mm - 32mm



New Profile

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Product: Brunswick

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Winton

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Braybrook

Width: From 67mm to 240mm
Thickness: 18mm - 32mm

EDWARDIAN

Edwardian architecture is the style popular when King Edward VII of the United Kingdom reigned. Over time Edwardian architecture moved from the highly ornate and decorative style of the Victorian era to pared down elegance and some would argue almost a masculinity.



Lambs Tongue BB

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*




Ashwood

*Width: 140mm to 240mm
Thickness: 32mm*




Delahey

*Width: 85mm to 240mm
Thickness: 18mm - 32mm*




Sandford

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*



Bulla

*Width: 100mm to 240mm
Thickness: 18mm - 32mm*



Lambs Tongue Step 1 (Special)

*Width: 100mm to 240mm
Thickness: 25mm - 32mm*



Emington

*Width: 86mm to 240mm
Thickness: 18mm - 32mm*



Hawthorn

*Width: From 92mm to 240mm
Thickness: 18mm - 32mm*



Rockdale

*Width: 92mm to 240mm
Thickness: 18mm - 32mm*

EDWARDIAN



Brim

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Wepar

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Lambs Tongue Step 2 (Special)

Width: From 140mm to 240mm
Thickness: 25mm to 32mm





Chatsworth

*Width: 140mm to 240mm
Thickness: 32mm*



Splayed Arc

*Width: 67mm to 240mm
Thickness: 12mm - 32mm*



Bullnose

*Width: 42mm to 240mm
Thickness: 12mm to 32mm*




Langley

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*



Seabrook

*Width: 110mm to 240mm
Thickness: 18mm - 32mm*




Palladio

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*


HERITAGE

Australia's heritage, shaped by nature and history, is passed from one generation to the next. It encompasses many things: ways of living, language, law, traditions, histories, stories, values, places, objects, resources and knowledge. It is also reflected in the natural and cultural diversity of places and objects that help us to understand our past, our place on the continent, and our effect on the Australian landscape. This report is about places of natural and cultural heritage significance and their related objects and Indigenous languages



Chatsworth

Width: 140mm to 240mm
Thickness: 32mm



Splayed Arc

Width: 67mm to 240mm
Thickness: 12mm - 32mm



Seabrook

Width: 110mm to 240mm
Thickness: 18mm - 32mm




Bullnose

Width: 42mm to 240mm
Thickness: 12mm to 32mm



Langley

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Palladio

Width: 67mm to 240mm
Thickness: 18mm - 32mm

FEDERATION

Coinciding with the birth of a nation, Federation, much like the separate states that were coming together as one, reflects a wide variety of influences. Including styles such as Romanesque, that were popular in another relatively new nation, the United States.



Strathmore

*Width: 110mm to 240mm
Thickness: 18mm - 32mm*



Malvern

*Width: 140mm to 240mm
Thickness: 32mm*



Kensington

*Width: 180mm to 240mm
Thickness: 32mm*



Lexton

*Width: 85mm to 240mm
Thickness: 18mm - 32mm*



Heathcote

*Width: From 110mm to 240mm
Thickness: 18mm - 32mm*



Fairfield

*Width: 85mm to 240mm
Thickness: 18mm - 32mm*



Federation

*Width: 42mm to 240mm
Thickness: 12mm - 32mm*

ART DECO

Terms such as symmetrical and cubism are used to describe Art Deco homes. Classical and elegant, Art Deco architecture is often embellished with themes from nature such as stylised floral motifs.




Modern Step

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Modern Step 2

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Special Order

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Step No. 1

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Step No. 2

Width: 85mm to 240mm
Thickness: 18mm - 32mm



Step No. 3

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Step No. 4

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No. 5

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No. 6

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No.7

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Step No.8

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No.10

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No. 11

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No. 12

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Step No. 13

Width: 85mm to 240mm
Thickness: 18mm - 32mm




Step No. 14

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Step No. 15


Width: 85mm to 240mm
Thickness: 18mm - 32mm



Step No. 16

Width: 67mm to 240mm
Thickness: 18mm - 32mm

VISUAL ROOM




CORNER BLOCK

ARCHITRAVES

DECORATIVE MOULD

BASE BLOCK

VISUAL ROOM



CORNICE

PICTURE RAIL


DADO RAIL

WINDOW NOSING

SCOTIA


SKIRTING BOARD

ART DECO



Product: Step No. 17

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*




Product: Step No. 18

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*




Product: Step No. 19

*Width: 85mm to 240mm
Thickness: 18mm - 32mm*



Anderson

Width: 42mm to 240mm
Thickness: 18mm - 32mm



Hadfield

Width: 67mm to 240mm
Thickness: 18mm - 32mm




Apsley

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Classic

Width: 110mm to 240mm
Thickness: 18mm - 32mm




Berrybank

Width: 67mm to 240mm
Thickness: 18mm - 32mm



California Bungalow

Width: 67mm to 240mm
Thickness: 18mm - 32mm



Classic RC


Width: 90mm
Thickness: 18mm



Oakleigh


Width: 85mm to 240mm
Thickness: 18mm - 32mm

BUNGALOW



Product: Beade A

*Width: 90mm only
Thickness: 18 mm only*




Product: Beade B

*Width: 90mm only
Thickness: 18mm only*




Product: Beade C

*Width: 70mm only
Thickness: 18mm only*




Product: Balaklava

*Width: 90mm to 240mm
Thickness: 18mm - 32mm*




Product: Buffalo

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*




Product: Munro

*Width: 67mm only
Thickness: 18mm only*



Product: Pyramid

*Width: 90mm
Thickness: 18mm*




Product: Pyramid Extended

*Width: 100mm to 240mm
Thickness: 18mm - 32mm*



Product: Biccara

*Width: 92mm to 240mm
Thickness: 18mm - 32mm*




Product: Modern Profile

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*



Product: Berwick

*Width: 67mm to 240mm
Thickness: 12mm - 32mm*



Product: Single Bevel

*Width: 42mm to 240mm
Thickness: 12mm - 32mm*




Product: Pallara

*Width: 67mm to 150mm
Thickness: 18mm - 32mm*




Product: Clayton

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*



Product: Apendale

*Width: 67mm to 240mm
Thickness: 18mm - 32mm*




Product: Half Bevel

*Width: 42mm to 240mm
Thickness: 12mm - 32mm*



Product: Rochester

*Width: 92mm to 240mm
Thickness: 12mm - 32mm*



Product: Quarter Bevel

*Width: 42mm to 240mm
Thickness: 12mm - 32mm*

MODERN/CONTEMPORARY



Edithvale

Width: From 85mm to 240mm
Thickness: 18mm - 32mm



Kingston

Width: 67mm to 240mm
Thickness: 12mm to 32mm



Pencil Round

Width: 42mm to 240mm
Thickness: 12mm to 32mm




Dressed All Round

Width: From 30mm to 1200mm
Thickness: 4mm - 32mm




WINDOW



Window Nosing

Width: 40 - 240mm
Thickness: 32mm



Scotia

Width: 32 x 32mm
Thickness: 32mm



Ovolo


Width: 32 x 32mm
Thickness: 32mm

SPECIALIZED




Rosebud

*Width: 70mm only
Thickness: 12mm - 18mm*



Rye

*Width: 50mm only
Thickness: 12mm - 18mm*




Shoreham

*Width: 45mm only
Thickness: 12mm - 18mm*




Somers

*Width: 40mm only
Thickness: 12mm - 18mm*



Risdon

*Width: 35mm only
Thickness: 18mm only*




Bena

*Width: 45mm only
Thickness: 12mm - 18mm*




Bega

*Width: 60mm
Thickness: 12mm - 18mm*



Bemboka


*Width: 60mm
Thickness: 18mm*



Riverton

*Width: 40mm only
Thickness: 18mm only*

DADO RAILS



Everton

Width: 90mm
Thickness: 32mm




Picture Rail 32mm

Width: 75mm
Thickness: 32mm



Crowne E

Width: 90mm
Thickness: 32mm




Margate

Width: 35mm only
Thickness: 18mm only



Casula

Width: 45mm
Thickness: 32mm



Wagga

Width: 60mm
Thickness: 32mm




Braddon

Width: 60mm
Thickness: 32mm



Throsby


Width: 70mm
Thickness: 32mm



Phillip


Width: 90mm
Thickness: 32mm

DADO RAILS




Weston

Width: 65mm
Thickness: 32mm




Cove

Width: 80mm
Thickness: 32mm




Saratoga

Width: 67mm
Thickness: 32mm



Eastwood

Width: 90mm
Thickness: 32mm




Crown A

Width: 60mm
Thickness: 32mm



Crown B

Width: 90mm
Thickness: 32mm



Crown C

Width: 60mm
Thickness: 32mm



Dallas

Width: 100mm to 240mm
Thickness: 18 mm to 32 mm

DADO RAILS




Kerang

*Width: 110mm Only
Thickness: 32mm Only*




Benowa

*Width: 60mm
Thickness: 32mm*




Kingscliff

*Width: 70mm
Thickness: 32mm*




Elanora

*Width: 70mm
Thickness: 32mm*



Taylor


*Width: 70mm
Thickness: 32mm*



Condong


*Width: 90mm
Thickness: 32mm*

PICTURE RAILS




Victorian Picture Rail B

*Width: 40mm and 60mm
Thickness: 18mm*



Picture Rail Eye Drop


*Width: 40mm and 60mm
Thickness: 18mm*



Victorian Picture Rail A

*Width: 40mm and 60mm
Thickness: 18mm*

CORNICES



Cornice 1

Width: 75mm
Thickness: 18mm



Cornice 2

Width: 90mm
Thickness: 32mm



Corner Block




72mm x 72mm x 18mm
92mm x 92mm x 18mm
95mm x 95mm x 25mm
120mm x 120mm x 18mm
Custom sizes available

Door Jamb



Width: 70mm and 240mm
Thickness: 12mm - 32mm

Triangle/ Corner



Width: 19mm
Thickness: 18mm

INSTALLATION INSTRUCTIONS

Fixing with Nails: When fixing with nails, a simple pre drill will reduce the chance of splitting the mouldings, particularly if you need to nail through the edge. If this is not possible, then skew nailing will greatly reduce the chance of splitting. The recommended nail sizes are as follows:

<i>Moulding Thickness</i>	<i>Nail Diameter x Length</i>
12mm	02 x 40mm
15mm	02.5 x 40mm
18mm	02.5 x 40mm
32mm	03.5 x 50mm

Nailing Jamb Heads to Stiles: When nailing jamb heads to stiles, skew the nail through the head of the jamb, towards the core and along the plane of the stile. Gluing is also recommended for added holding strength. For best results however, we recommend fixing jamb heads to stiles with screws.

Nailing Architrave Mitre Joints: When nailing the architrave mitre joints, skew the nail towards the core and along the plane. Gluing is also recommended for added holding strength.

Nailing Architraves to Door Jambs: When nailing architraves to the edge of the door jamb, nails should be skewed towards the core of the jamb. Best results are achieved by also gluing the architraves to the jamb.

Fixing with Staples: For best results use narrow crown staples, sencoated N4450. The staple's length should give fixing into the timber frame of at least the moulding's own thickness. The air pressure of the staple gun should be controlled to avoid excessive penetration of the staple, which may reduce holding power.

Fixing with Adhesive: If using adhesives use a reputable brand of contact, stud or wallboard adhesive. We recommend a construction adhesive.

Fixing with Screws: When fixing with screws, use only parallel thread screws such as particleboard or twinfast screws. For best results pilot holes should be drilled into the moulding slightly beyond the full depth of the screw penetration. The pilot hole diameter should be 80% of the screw core diameter and of the right gauge for the thickness of the moulding. If screwing through the edge use the smaller gauge recommendations for the moulding thickness and place screw at least 25mm from the corner. Countersink and fill with stopping compound. Check this table for correct sizes:

<i>Moulding Thickness</i>	<i>Screw Gauge Number</i>
12mm	4 or 5 gauge
15mm	4 or 5 gauge
18mm	6 or 7 gauge
32mm	6 or 7 gauge

Secure mouldings at a maximum of every 600mm using glue as well as nails or screws for fixing. Apply a 1-2mm bead of adhesive between joints if fixing lengths longer than 3 lineal metres and glue all cut ends. Use a paintable, flexible sealant adhesive such as Selleys "No More Gaps." If these precautions are not taken and shrinkage does occur, any open joints that appear can be simply fixed by filling with sealant adhesive described above. Mouldings have a high internal bond strength. So an excellent holding performance is guaranteed regardless of whether you are using screws, staples or nails.

Finishing and Painting

Mouldings are pre primed with a durable acrylic polymer, so an additional undercoat is not necessary. Professional results can be achieved with acrylic or enamel paint, in a gloss or sartin finish depending on the desired finish and effect. We recommend that the paint manufacturer's instructions are followed for best results.

STORAGE & PREPARATION

Care should be taken when storing mouldings because as tough as they may be, they are vulnerable to certain conditions. Always keep mouldings in the original, pre-packaged plastic lined boxes, away from sunlight, hot winds, or damp/wet areas, for at least 48 hours before installation. This is because mouldings are wood based, so they expand and contract like natural wood when moisture is gained or lost – especially when exposed to extreme changes in weather.

Never store mouldings directly on concrete floors without timber bearers and some form of protection underneath. And never fix mouldings to newly rendered surfaces or surfaces with a moisture content above 15%. Air conditioned buildings may also cause minor shrinkage if mouldings are not allowed to get accustomed to such conditions before fixing.

Do not fill and paint the job until the fit-out has been allowed a minimum of 48 hours to adapt to the prevailing controlled conditions

Exposure Control and Personal Protection

Summary

Keep exposures as low as practicable with the aim of maintaining airborne dust levels below 1.0 mg/m³ time-weighted average (TWA), measured as inspirable dust. All work with wood panel products must be carried out in such a way as to minimise exposure to dust. Under factory conditions, machining, sawing, drilling, routing, laser cutting or sanding of the wood, must be done with equipment fitted with local exhaust ventilation devices capable of removing dust and smoke at source. Work areas should be kept clean by regular vacuuming or wet sweeping.

Ventilation

Local exhaust ventilation should be provided at areas of cutting to remove airborne dust. General dilution ventilation should be provided as necessary to keep airborne dust below the applicable exposure limits and guidelines. The need for ventilation systems should be evaluated by a professional industrial hygienist, while the design of specific ventilation systems should be conducted by a professional engineer.


Special Consideration for Repair/Maintenance of Contaminated Equipment: Use personal protective equipment as discussed above. Where possible, vacuum all equipment before repair/maintenance to remove excessive dust.

Eye: Non-fogging dust resistant safety goggles or glasses conforming with Australian and New Zealand Standards AS/NZS 1336:1997. Recommended practices for occupational eye protection, should be worn if there is a risk of dust getting into the eye, such as when using power tools.

Skin: Wear standard duty gloves conforming with Australian Standards AS 2161.1 2000 Industrial safety gloves and mittens, loose comfortable clothing and boots. Long-sleeved shirts and long trousers are recommended. If skin itching occurs, wash skin with mild soap and water after working with these products. Wash work clothes regularly and separately from other clothes.

Respiratory: Avoid breathing dust. Wear a P1 or P2 particulate disposable or cartridge dust mask, (respirator), conforming with Australian and New Zealand Standards AS/NZS 1715:2009 Selection, use and maintenance of respiratory protective devices, and AS/NZS 1716:2003 Respiratory protective devices, when exposed to dust. These Standards should be followed in the selection, fit-testing, use, storage and maintenance of the dust masks.

Smoking: Inhalation of airborne particles from other sources, including those from cigarette smoke, may increase the risk of lung disease. All storage and work areas should be smoke free zones and other airborne contaminants be kept to a minimum.



Primed MDF Mouldings
Skirtings
Architraves
Door Jambs

Botany Bay Timber Products Pty. Ltd.
21 - 31 Lance Road, North Sunshine
Victoria 3020

website www.botanybay.com.au
email www.botanybaytimber@mail.com